



### 1. Characteristics

- \* TOYOCAT-D60 has less odor and exhibits a mild gelling activity which is not thermo-sensitive, that is, its catalytic activity is not strongly dependent on temperature.
- \* TOYOCAT-D60 provides improved moldability and curing function even at low mold temperature in flexible molded foam systems.
- \* TOYOCAT-D60 can be also used for flexible slabstock and rigid foams.

### 2. Typical Properties

Appearance	Yellowish clear liquid
Specific Gravity $D_{20}^{20}$	0.79
Water Content (%)	< 0.5
Solubility in Water	Insoluble
Freezing Point ( )	< -20
Flash Point ( ) [C.O.C]	112
Viscosity (mPa s) (at 25 )	39
Calculated OH number (mgKOH/g)	0

### 3. Toxicity

Oral (rat) LD <sub>50</sub>	740 mg/kg
-----------------------------	-----------

### 4. Handling and Storing

This product has a low vapor pressure and toxicity, however handling in well ventilated area is recommended.

When this product comes into direct contact with the eyes or skin, inflammation will occur. Wearing protective gear or applying protective cream is most effective when handling. In the event that contact is made with the eyes or skin, wash immediately with large amount of water. If the eyes are affected, seek medical attention after washing. This product may turn slightly darker when stored over long periods of time. However, catalytic activity will not be affected.

This product has a possibility of precipitating the white sediments by forming the carbonates with carbon dioxide in air. So it needs to displace the inside with nitrogen and keep the drum airtight after opening.

## 5 Shipping information

Net weight

Packaging	kg	1b
Drum (200L)	150	330
(20L)	15	33

---

## TOSOH CORPORATION

### CORPORATE OFFICE:

TOSOH CORPORATION  
Organic Chemicals Division  
Shiba-koen First Building, 3-8-2 Shiba,  
Minato-ku, Tokyo 105-8623, Japan  
Phone: 81-3-5427-5164  
Fax: 81-3-5427-5215  
E-mail: fc\_amine@tosoh.co.jp

### EUROPE OFFICE:

TOSOH EUROPE B.V.  
Crown Building-South,  
Hullenbergweg 359,  
1101 CP Amsterdam Z.O., The Netherlands  
Phone: 31-20-5650010  
Fax: 31-20-6915458  
E-mail: tosoh@tosohur.com

### USA OFFICE:

TOSOH USA, INC.  
Suite 600, 1100 Circle 75 Parkway, Atlanta,  
Georgia 30339-3097, U.S.A.  
Phone: 1-770-956-1100  
Fax: 1-770-956-7368  
E-mail: info@tosohusa.com

### SINGAPORE OFFICE:

TOSOH FINE CHEMICALS PTE., LTD.  
133 Cecil Street #15-01,  
Keck Seng Tower, Singapore 069535  
Phone: 65-226-5106  
Fax: 65-226-5215  
E-mail: tfccah@cyberway.com.sg

*Visit us at [www.tosoh.com](http://www.tosoh.com)!*