



1. Characteristics

- * TOYOCAT-RX20 is a reactive amine catalyst, which exhibits a well balanced blowing and gelling catalytic activity. Besides amine emission from the foam is almost free.
- * TOYOCAT-RX20 can be used for HR formulation, which exhibits excellent foam flowability, moldability and curing functions.
- * TOYOCAT-RX20 can also be used for both flexible slabstock foam and hot cure foam to provide less-fugitive.

2. Typical Properties

Appearance	Yellowish clear liquid
Specific Gravity D_{20}^0	0.88
Water Content (%)	< 0.7
Solubility in Water	
Freezing Point ()	< 0
Flash Point () [T.C.C]	43
Viscosity (mPa s) (at 25)	25
Calculated OH number (mgKOH/g)	532

3. Toxicity

Oral (rat) LD ₅₀	1820 mg/kg
-----------------------------	------------

4. Handling and Storing

This product has a low vapor pressure and toxicity, however handling in well ventilated area is recommended.

When this product comes into direct contact with the eyes or skin, inflammation will occur. Wearing protective gear or applying protective cream is most effective when handling. In the event that contact is made with the eyes or skin, wash immediately with large amount of water. If the eyes are affected, seek medical attention after washing. This product may turn slightly darker when stored over long periods of time. However, catalytic activity will not be affected.

5 Shipping information

Net weight

Packaging	kg	lb
Drum (200L)	170	374
(20L)	16	35

TOSOH CORPORATION

CORPORATE OFFICE:	TOSOH CORPORATION Organic Chemicals Division Shiba-koen First Building, 3-8-2 Shiba, Minato-ku, Tokyo 105-8623, Japan Phone: 81-3-5427-5164 Fax: 81-3-5427-5215 E-mail: fc_amine@tosoh.co.jp
EUROPE OFFICE:	TOSOH EUROPE B.V. Crown Building-South, Hullenbergweg 359, 1101 CP Amsterdam Z.O., The Netherlands Phone: 31-20-5650010 Fax: 31-20-6915458 E-mail: tosoh@tosoheur.com
USA OFFICE:	TOSOH USA, INC. Suite 600, 1100 Circle 75 Parkway, Atlanta, Georgia 30339-3097, U.S.A. Phone: 1-770-956-1100 Fax: 1-770-956-7368 E-mail: info@tosohusa.com
SINGAPORE OFFICE:	TOSOH FINE CHEMICALS PTE., LTD. 133 Cecil Street #15-01, Keck Seng Tower, Singapore 069535 Phone: 65-226-5106 Fax: 65-226-5215 E-mail: tfccah@cyberway.com.sg

Visit us at www.tosoh.com!